BRAVAT TRIO MOTION SENSOR FAUCET BLACK FINISH INSTALLATION INSTRUCTIONS

Fontana Sensor Faucets[©]




PRIOR TO INSTALLATION

Fontana Sensor Faucet

Please read installation instructions below. All plumbing should be installed in accordance with applicable building codes and regulations.

Unpack and inspect the items for any shipping damages. If you find damages, do not install.

All products must be installed by a professional and certified plumber otherwise warranty may be voided.



1

fontanasensorfaucets.com Customer Service: 800-684-4489

Fontana Sensor Faucets[©]-

Technical Information

Power: DC:6V(4AA alkaline battery) AC:220V-240V; 50/60HZ

Detection Zone: 16-32 cm or adjustable Motor valve lifespan: up to 500000 flushes Battery lifespan: 100000 cycles

Static Power Consumption: 0.36mw

Working Power consumption: 0.5mw

Inductive Opening Time: < 1 second

Inductive Closing Time: < 2 second

Flow rate at 3 bar flow pressure for basin: \ge 12 L/min

Flow pressure: min. 0.5 bar - recommended 1 – 5 bar

Faucet Body

Threaded Tube

Rubber Washer

Nut and locking bolts

O ring


Washer

Operating pressure: max. 10 bar


Test pressure: 16 bar

Hole Size Chart

Faucet Deck Mount Installation



Faucet Size



All dimensions and specifications are nominal and may vary. Use actual products for accuracy in critical situations.

1.38"/35mm

Max counter top thickness without

deck plate:




Pre-drilled hole size requirements:

Min: 1.26"/32mm - Max: 1.38"/35mm


Fontana Sensor Faucets^{©-}

Installation Instructions


Step 1:




Step 2:




Step 3:



Step 4:




Fontana Sensor Faucet



Fontana Sensor Faucets[©]

<u>Step 7:</u>

<u>Step 8:</u>



1. Before installation, please make sure the power is turned off.

2. When connecting the control line and power line according to the arrow, please note the male and female to prevent the circuit board from burning out, because of the incorrect connection.

3. Be sure the washer installed to prevent impurities into the water valve to avoid leakage.

4. Overtime protection: Continuous induction water for more than 60 seconds, it will stop automatically.

5. When abnormal (No Induction but water out etc.), hold down the reset switch on the sensor box 3 seconds then release (When press the reset switch the sensor does not action), the control circuit repower, return to normal.

Flexible Connecting Hose

Care must be taken when connecting the flexible connection hose from the power supply box to the spout to ensure it does not bend sharply and kink or twist. See above for recommended ways to fit the flexible connecting hose.

Important: Failure to follow these guidelines may result in poor performance and damage to the flexible connection hose.

Specifications Flow pressure: min. 0.5 bar - recommended 1 – 5 bar Operating pressure: max. 10 bar Test pressure: 16 bar Flow rate at 3 bar flow pressure for basin: ≥ 12 L/min Hot water inlet temperature: max. 80°C Recommended (energy saving): 60°C Environment temperature: 5°C ~ 45°C

Power:

Dc type: AA Size 1.5V Battery, 4 pcs Ac type (for European standard): Input 220V, Output 6V/500mA Sensing Distance: 16-20 cm Sensing Duration: 1 second Battery Lift Time: Appr. 50,000 cycle Supply Water Pressure: 0.5-5 kgf/cm2 Ambient Temperature: 5°C - 45°C (Supply Water Temperature 5°C - 50°C) Supply Water Pipe Specification: G1/2 Non-working Power Consumption: ≤0.5 mW

Fontana Sensor Faucet

Fontana Sensor Faucets[©]-

Battery Override

In the event of a power failure, the sensor faucet will automatically switch to battery-operated mode to ensure the faucet continues to function. The sensor faucet can also operate on the battery alone if no main power source is available.

Set Water Flow Time-Out

The sensor faucet will shut off the water when washing time exceeds 1.5 minutes. If follow-up washing is needed, re-induce after removing hands for 2 seconds.

Notes

1. Please use the AA type alkaline battery (1.5v for each).

2. Place batteries into each indicated spot. Utilizing new batteries of the same brand is best. If mixed, it could shorten the battery life to 1-2 months.


3. After installation of the battery, the solenoid valve will do its self-testing.

4. Wait ten seconds for power to be applied and allow the sensor faucet to self-adjust sensor distance. Do not use your faucet during this time.

5. If the sensor distance is too short, please move the barrier from the faucet for 5-6 mins and allow the sensor faucet to adjust to normal.

6. If the sensor distance is too far, and water flows continuously, the sensor faucet will self-adjust the distance after 5 mins.


Correct way for Hose



Sensor Range

This sensor faucet can automatically adjust the inductive range within 10 seconds of electrification. Do not use inductor during this period so that the inductor can automatically adjust to a suitable inductive range.

Incorrect Placement



Keep sensor range adjustment within 4 inches away from center of spout. This can only be done with optional remote control. Dispenser

Faucet

Soap

Installing electronic soap dispenser & faucet with intersecting centerline might lead to accidental activation of either or both.





General Information

Our sensor spouts have a non-touch control which uses infrared sensing technology to detect human presence. Once detected, the spout instantly dispenses water and automatically stops once the user moves their hands away to eliminate unnecessary water wastage, whilst creating a more hygienic washroom solution.

All products manufactured and supplied by Fontana are safe and comply to legislative requirements. Providing they are installed correctly and receive regular maintenance in accordance with these instructions your user experience will not be affected.

Hygienic

The proximity sensor faucet removes the need to touch the faucet body, reducing the spread of germs and the chance of cross-contamination.

Fontana Sensor Faucet